


# Connection diagram Linkbox

## Connections front



### CAN2 + IOs

Plug type: Socket  
5-pin

Encoding: A

#### Pin description:

6. IO2
7. IO1
8. 0V / GND / Mass
9. CAN2 High
10. CAN2 Low

### CAN1 + Power

Plug type: pin  
5-pin

Encoding: A

#### Pin description:

6. Shielding
7. VIN / Supply
8. 0V / GND / Mass
9. CAN1 High
10. CAN1 Low

### LTE

To connect an antenna for  
LTE

### GPS

To connect an antenna for  
GPS

## Rear panel connectors (Ethernet link boxes only)



### Standard M12 Ethernet connector

Plug type: 4 pole socket

Codierung: D

#### Pin description:

5. TX+
6. RX+
7. TX-
8. RX-